## SV-5 Siding Vent



Crush-resistant: Will not compress like "drainage mat" products
James Hardie® recommended, unlike "drainage mat" products

• Impact-resistant: screw, staple or power-nail in place

(see: http://www.jameshardiecommercial.com/pdf/HardiePanel-Rainscreen-Quick-Reference-Guide.pdf)

## Q: How much SV-5 do I need?

A: SV-5 runs linearly along the top and bottom of the wall, as well as above and below windows or doors. Take the total length of all walls and multiply by 2 (for top and bottom), then account for above and below wall penetrations to determine how many linear feet of SV-5 you will need.

